





Rigid Shaft Coupling KBS 95



KBS 95 Rigid Shaft Coupling is a frictionally engaged detachable shaft-hub connection for cylindrical shafts without keyway.





Features

- delivered in mounted condition
- self-centering
- concentricity **0,02 – 0,04 mm**

Tolerances, Surfaces

- a good turning process is sufficient: **Rz ≤ 16 µm**
- maximum tolerance: **d = h8 for shafts**

Components of the rigid shaft coupling KBS 95




Image 2) KBS 95

Component	Quantity	Description
1	1	front outer ring (through holes)
2	1	inner ring (slotted)
3	1	rear outer ring (with threaded holes)
4	see catalogue	socket head screw ISO 4762




Information!

Contaminated or used clamping sets have to be detached and cleaned prior to installation. Then apply a thin layer of low viscosity oil (e.g. Castrol 4 in 1 or Klüber Quietsch Ex).




Assembly of the coupling

- Check shaft-position regarding the stipulated tolerance (h8).
- The contact surfaces of the shafts to be connected have to be cleaned and degreased. Then apply a thin layer of low viscosity oil (e.g. Castrol 4 in 1 or Klüber Quietsch Ex).

 ATTENTION!	<p>Do not use any oil or grease containing molybdenum-disulphide or high pressure additives as well as sliding-grease paste.</p>
--	--

- Loosen the clamping screws. (Do not remove them!) Place the rigid shaft coupling KBS 95 onto the shaft ends to be connected.
- Slightly tighten the clamping screws manually and align both the rigid shaft coupling and the shafts. (see image 3).



- Tighten the clamping screws crosswise and evenly. Increase tightening torque gradually. Repeat this procedure until the tightening torque specified in table 1 has been reached by all clamping screws.

Table 1:

Rigid Shaft Coupling	KBS 95				
	M6	M8	M10 - Ø70, 75	M10 - Ø80, 85, 90	M12
Thread Size M	M6	M8	M10 - Ø70, 75	M10 - Ø80, 85, 90	M12
Tightening Torqu T _A [Nm]	17	41	83	71	143



Disassembly of the coupling



DANGER!

Loosened or falling drive components may result in personal injuries or damage to machines. Please secure all drive components prior to disassembly.

- Loosen all clamping screws evenly in sequence. Do not unscrew the clamping screws completely from the thread.
- Shaft couplings are not self-locking. In case the outer and inner tapered ring do not come loose, start the detachment process by a slight pressure onto several parts of the circumference.
- Remove the shaft from the rigid shaft coupling KBS 95.



ATTENTION!

Non-observance of these instructions or non-consideration of operating conditions selecting the clamping set may impair the function.

Disposal: *Defective shaft couplings have to be cleaned and scrapped.*

